



**Pro's Choice**  
EXCLUSIVE DISTRIBUTOR FOR  **GRAPHITE DESIGN.**



## 2026 WOOD SHAFT INSTALLATION AND TRIMMING GUIDE

### TOUR AD/JAPAN WOOD SHAFTS:

CLUB	PRODUCT TYPE	STD-BORE HOSEL	BLIND BORE HOSEL	THRU BORE HOSEL	NOTES
DRIVERS	TOUR AD FI, GC, VF, CQ, UB, HD, XC, DI & IZ	0.0"	0.0"	Insert 2.5" only	3.0" of Tip Parallel
DRIVERS	Anti-Gravity aG33-3	0.0"	0.0"	Insert 2.5" only	3.0" of Tip Parallel
CLUB	PRODUCT TYPE	STD-BORE HOSEL	BLIND BORE HOSEL	THRU BORE HOSEL	NOTES
#3 WOOD	TOUR AD F-Series FWY	0.5"	0.5"	0.5" - then Insert 2.0"	3.0" of Tip Parallel
#3 WOOD	TOUR AD FI, GC, VF, CQ, UB, HD, XC, DI & IZ	0.5"	0.5"	0.5" - then Insert 2.0"	3.0" of Tip Parallel
#3 WOOD	Anti-Gravity aG33-3	0.5"	0.5"	0.5" - then Insert 2.0"	3.0" of Tip Parallel
CLUB	PRODUCT TYPE	STD-BORE HOSEL	BLIND BORE HOSEL	THRU BORE HOSEL	NOTES
#5- #9 WOOD	TOUR AD F-Series FWY	1.0"	1.0"	0.5" - then Insert 2.0"	3.0" of Tip Parallel
#5- #9 WOOD	TOUR AD FI, GC, VF, CQ, UB, HD, XC, DI & IZ	1.0"	1.0"	0.5" - then Insert 2.0"	3.0" of Tip Parallel
#5- #9 WOOD	Anti-Gravity aG33-3	1.0"	1.0"	0.5" - then Insert 2.0"	3.0" of Tip Parallel

\* Pro's Choice encourages consulting a PGA Professional or qualified club builder to help you determine the correct shaft and length for your swing profile and to meet your goals.

\* Always leave a minimum of 0.5" of the parallel tip section of the shaft above the hosel. For example with a hosel depth of 1.5" and a parallel tip length of 4.0", the tip trim length should not exceed 2.0".

\* Improper installation may effect the intended performance of the shaft. Warranty is for material and workmanship of our products. Improper installation voids warranty of product.



**Pro's Choice**

EXCLUSIVE DISTRIBUTOR FOR  **GRAPHITE DESIGN.**



**GRAPHITE DESIGN™**  
PREMIUM GOLF SHAFTS

## 2026 US SPEC WOOD SHAFT INSTALLATION AND TRIMMING GUIDE

### DOMESTIC / US WOOD SHAFTS:

CLUB	PRODUCT TYPE	STD-BORE HOSEL	BLIND BORE HOSEL	THRU BORE HOSEL	NOTES
DRIVERS	MAD 45, 55, 65, 75 & MAD PRO 65, 75	0.0"	0.0"	Insert 2.0" only	3.0" of Tip Parallel
CLUB	PRODUCT TYPE	STD-BORE HOSEL	BLIND BORE HOSEL	THRU BORE HOSEL	NOTES
#3 WOOD	MAD 45, 55, 65, 75 & MAD PRO 65, 75	0.5"	0.5"	0.5" - then Insert 2.0"	3.0" of Tip Parallel
CLUB	PRODUCT TYPE	STD-BORE HOSEL	BLIND BORE HOSEL	THRU BORE HOSEL	NOTES
#5- #9 WOOD	MAD 45, 55, 65, 75 & MAD PRO 65, 75	1.0"	1.0"	0.5" - then Insert 2.0"	3.0" of Tip Parallel

\* Pro's Choice encourages consulting a PGA Professional or qualified club builder to help you determine the correct shaft and length for your swing profile and to meet your goals.

\* Always leave a minimum of 0.5" of the parallel tip section of the shaft above the hosel. For example with a hosel depth of 1.5" and a parallel tip length of 4.0", the tip trim length should not exceed 2.0".

\* Improper installation may effect the intended performance of the shaft. Warranty is for material and workmanship of our products. Improper installation voids warranty of product.



**Pro's Choice**  
EXCLUSIVE DISTRIBUTOR FOR  **GRAPHITE DESIGN.**



## 2026 HYBRID & IRON SHAFT INSTALLATION AND TRIMMING GUIDE

### ALL HYBRID AND IRON SHAFTS:

CLUB	PRODUCT TYPE	15°-18°	19°-22°	23°-26°	27°+	NOTES
HYBRIDS	TOUR AD VF HYBRID 75,85,95, 105 (.370" tip)	0.0"	0.0"	0.0"	0.0"	Install Straight In and then butt trim to final desired club length.
HYBRIDS	TOUR AD IZ HYBRID 65,75,85,95 (.370" tip)	0.0"	0.5"	1.0"	1.0"	Tip trim then butt trim to final desired club length.
HYBRIDS	TOUR AD DI 75,85,95 & 105 (.370" tip)	0.0"	0.5"	1.0"	1.0"	Tip trim then butt trim to final desired club length.
HYBRIDS	TOUR AD HY 65,75,85 & 95 (.370" tip)	0.0"	0.5"	1.0"	1.0"	Tip trim then butt trim to final desired club length.
CLUB	PRODUCT TYPE					NOTES
IRONS	Tour AD 50 Iron (.370" Tip OD with 1 3/8" parallel tip section) No Tipping. Insert straight in and butt trim to desired final club length.					
IRONS	Tour AD 65, 75 85, 95 Iron (.355" Taper Tip) No Tipping. Insert straight in and butt trim to desired final club length.					
DRIVING IRONS	Tour AD VF UT 95g and 105g Driving Irons, Tour AD DI UT (Orange) 85g and 95g Driving Irons, Tour AD UT 85g and 95g (Black) Driving Irons – .355" taper tip. No tip trimming. Install straight in and Butt cut to desired final club length.					
IRONS	Tour AD 105 & 115 Iron gram weights- these shafts are combo flex shafts. Please contact Pro's Choice sales at 619-454-6283 or 760-476-9598 for tipping instructions.					

### RAUNE IRON SHAFT INSTALLATION AND TRIMMING GUIDE

CLUB	PRODUCT TYPE	#3 Iron	#4 Iron	#5 Iron	#6 Iron	#7 Iron	#8 Iron	#9 Iron	#10/Wedge
IRONS	RAUNE 60g (.370" Tip OD with 4" of Parallel)	0.0"	0.0"	0.0"	0.5"	1.0"	1.5"	2.0"	2.5"
IRONS	RAUNE 75g (.370" Tip OD with 4" of Parallel)	0.0"	0.0"	0.0"	0.5"	1.0"	1.5"	2.0"	2.5"
IRONS	RAUNE 90g (.370" Tip OD with 4" of Parallel)	0.0"	0.0"	0.0"	0.5"	1.0"	1.5"	2.0"	2.5"
IRONS	RAUNE 105g (.355 Taper Tip) No Tipping	Insert Straight in and butt trim to desired final club length							